

SOFT MONITOUCH **TELLUS and V-Server**

▲ Safety Considerations

- For safe operation, read the instruction manual or user manual that comes with the product carefully or consult the distributor from which you purchased the product, before using the product.
- Products introduced in this catalog have not been designed or manufactured for such applications in a system or equipment that will affect human bodies or lives.
- Customers, who want to use the products introduced in this catalog for special systems or devices such as for atomic-energy control, aerospace use, medical use, passenger vehicle, and traffic control, are requested to consult the Hakko Overseas Sales Section.
- Customers are requested to prepare safety measures when they apply the products introduced in this catalog to such systems or facilities that will affect human lives or cause severe damage to property if the products become faulty.
- For safe operation, wiring should be conducted only by qualified engineers who have sufficient technical knowledge about electrical work or wiring.

Notes to consider before purchasing

- Appearance and specifications are subject to modification without prior notice due to technical improvements.
- Colors in the catalog may differ from the actual colors due to printing inaccuracies.
- Consult your distributor or us for further information about products in this catalog.

www.monitouch.com

Sales company : Fuji Electric Co., Ltd.

URL : www.fujielectric.com/ Gate City Ohsaki, East Tower, 11-2, Osaki 1-chome, Shinagawa-ku, Tokyo 141-0032, Japan Phone: +81-3-5435-7066 Fax:+81-3-5435-7475

Manufacturer :

Hakko Electronics Co., Ltd. URL : www.monitouch.com/ 890-1 Kamikashiwano-machi, Hakusan, Ishikawa 924-0035, Japan Phone: +81-76-274-2144 Fax:+81-76-274-5136 E-mail : sales@hakko-elec.co.jp

Distributor	

Product specifications and design are subject to modification Combined images are used for the screen images. Product colors may differ from colors in brochure photos due to printing.
 Windows and Excel are trademarks of Microsoft (USA) in the U.S. and other countries
 Other company and product names in this brochure are registered trademarks. Bringing the factory floor to your desk



Innovating Energy Technology

SOFT MONITOUCH **TELLUS** and V-Server

Monitoring the factory from the office enables quick response to changes, improving operating efficiency.

TELLUS and V-Server links MONITOUCH in a factory with a PC in the office, so that you can remotelly collect on-site data or monitor and control the equipment in the factory. This combination enables efficient and low-cost production; immediate and appropriate responses to the condition of the production line is possible from anywhere.

P.4

P.6

P.7

STATES.

=MONITOUCH

=iPac

TELLUS-HMI iPad



Collection and saving of current data

V-Server

Linkage of a PC and MONITOUCH via Ethernet enables collection and saving of on-site data in real time.



TELLUS-Remote

Remote monitoring and control

Installation of the TELLUS and V-Server software package allows your PC to monitor and control the production site via MONITOUCH through Ethernet.

TELLUS-HMI

MONITOUCH functions available on your PC/iPad

Equivalent functions of MONITOUCH are available on your PC or iPad by directly connecting to PLC after installing TELLUS software. It is possible to show a screen image on a large PC display and link various Windows applications. By using on iPad, the control panel becomes portable.

Linking your office and factory for collection of production data $V^-Server$



Data saving without programming



Data logging function

Production data can be regularly read out and saved in database or CSV/ Excel format.

Readout of sampling data

Sampling data stored in MONITOUCH can be read out and saved in database or CSV/ Excel format.

Consolidated recipe data management

Consolidation of recipe data by the host PC reduces the process of recipe registration and modification for each equipment and provides consistent production control.



Consolidated data management for PLCs from various manufacturers and models

V-Server collects information from peripheral devices through MONITOUCH as a gateway. It is possible to collect information from devices of any manufacturer and model if they can be connected to MONITOUCH.



Easy to make daily and monthly reports (DDE function)

The tag data registered in V-Server can be pasted to Excel spreadsheet in DDE format. This makes it easy to generate daily/monthly reports.



Quick response to on-site problems

Alarm data can be monitored to display historical data or a list of alarms currently occurring. In addition, an e-mail alert can be sent immediately when a critical alarm occurs.



Reading and writing of stored data

Files on a SD card inserted in MONITOUCH can be read out to a PC, and files edited on a PC can be written onto a SD card via Ethernet.



Updating of MONITOUCH data from the office

You can update the system program of multiple MONITOUCH panels at a time or transfer the screen program to them all together.



Automatic actions in response to events

Various kinds of events can be set depending on the requirements of the operation. Events allow for a high degree of flexibility, so you can adapt to the specifications of the production line.

Event (Trigger conditions)							
Bit ON/OFF Value comparison Time setting							
Action (Operations)							
Start/Stop of logging	Sampling readout						
Application start-up Stored data read/write							

Remote monitoring and control TELLUS-Remote



Remote control with excellent cost performance



TELLUS allows you to control and monitor multiple MONITOUCH panels with a single PC, which helps improve the operating efficiency and the cost-effectiveness.



Security functions such as write-protect are provided to ensure safe and secure system operation

V-Server

Factory





Remote control by means of a simple system

The system is compatible with various systems such as in-house LAN, Internet, WAN, etc.

- You can access the on-site screen via the Internet from a remote location.
- You can monitor overseas plants via WAN.

*It is necessary to modify the setting of firewall and routing for Internet access.

Branch office TELLUS-Remote

WAN/ Interne Head office TELLUS-Remote

Realizing even higher performance with MONITOUCH by integrating PC/iPad into systems **TFIIUS-HMI**





Install anywhere, even on your palm

It enables new applications like controlling multiple machines with a single tablet or wirelessly operating a machine while visually monitoring where best.



Easy selection of peripheral equipment

It is possible to connect peripheral equipment such as printers and mass storage media that have Windows drivers so that the data can be easily output or saved.



Large expandability combined with various applications

Shutdown of

Processing of production data such as summary and analysis can be easily conducted using external software.



OS can be shut down on TELLUS without displaying the shutdown menu

OS

TELLUS and V-Server

TELLUS-HMI iPad

tellus-hmi

TELLUS-HMI





Various applications can be run. including that for viewing a PDF of the troubleshooting manual.



DLL functions that were made individually can be loaded and executed on TELLUS

Advantages of using V-Server

"I don't have to bother collecting data any more."



Real-time collection of on-site production data

Production data can be collected in real time without distracting workers. Collected data can be used for reviewing production plans and improving production facilities.





TELLUS and V-Server

Advantages of using TELLUS-HM "I won't miss a problem in production."

An image of the entire production line can be displayed on one large screen.

Equipping a PC with MONITOUCH functions makes it possible to have a large, full HD display. All operation processes can be displayed on one large screen.



Additional display only for monitoring is also available.

The dedicated TELLUS screen only for monitoring can be displayed on a large display.



Applica	able Models		Confi	guratior	Software				
V9 series TS2000i series TS1000 Smart series			V-SFT-6	V-SFT-6 Configuration software for MONITOUCH and TELLUS. You can easily create your own screen program as desire					
Please ensur	mended Operat e the following conditions are	ing Environment (PC) in place for the operation of TELLUS and V-Server	● Reco	mmende	ed Operating E	nvironment (iPad)			
PC	IBM PC/ AT compatib	ble with Windows	Applicable	Applicable models Use iPads of the model and system versions shown below.					
DS	Windows 10 (32bit, 6 7 (32bit, 64bit)/ Vista Server 2016/ Server 2	4bit)/ 8.1 (32bit, 64bit)/ 8 (32bit, 64bit)/ (32bit, 64bit)/ XP/XP64 Edition/ 2012/ Server 2008 R2	Model iPad	System v iPadOS1	ersion 3, iPadOS14				
CPU	Pentium IV 1GHz or I	more	Resolution	(1024×768),	then it becomes magnified	g on the model. Create the screen data at on an iPad screen (same aspect ratio) automatic			
/lemory	256MB or more (Whe	en an emulator is used, 512 MB or more)	iPa	d model	Solution	Remarks			
lard disk	When TELLUS instal	led: 2.5 GB or more	iPad Min		2048×1536	iPad Mini 2 or later			
	When V-Server instal	lled: 2.5 GB or more	iPad	10 5"	2224×1669	iPad 3 or later			
Display	Resolution: XGA 102	4×768 or more	iPad Pro	11.5	2388×1668	IIICI. IPAU AII S			
. ,	Colors: High Color 16	bit or more	iPad Pro	12.9"	2732×2048				
	-Serve ns of V-Server are	er		TEL					
The function carried out •Readout recipe da (or TELL •Alarm m •Event ac •Screen (excludin	-Server are by the server PC. / writing of the ata for MONITOUCH US HMI) toonitoring ction data transfer ig TELLUS-HMI)	Server PC V-Server Ethernet MONITOUCH PLC PLC	Alle five types of ficers A cl TELI on a and MOP HMI Allso	TEL ient PC equ LUS accesso server PC to operates the IITOUCH (i remotely. commun possible.	LUS - F Lipped with as V-Server via Ethernet a screens of or TELLUS ication is	Server PC Server PC Server PC Server PC Ethernet			

TELLUS-HMI iPad 5

possible

• iPad performs communications equivalent to the V series* by connecting to a PLC wirelessly. * Only models capable of Ethernet (TCP/IP) communication can connect.



License Validation

License validation is restricted to one license per device. There are five types of licenses, one for each function (See above). Check the type of license for the function(s) you wish to use it for. Note*: When reinstalling the application software on the same computer, the same password is valid. However, if you initialize the OS or change the device to use the application software, the password becomes invalid. In this case, you must go through the license validation procedure again to get a new password. *Excluding the cases of using a USB license key

<u>) (4</u> TELLUS-HMI iPad

Password validation

TELLUS-HMI/ TELLUS-HMI iPad

TELLUS-Remote

TELLUS and V-Server

V-Server

PLC models compatible with **TELLUS**

	V9 series			TELLUS Ver.4				TELLUS Ver.3			
Manufacturer	Models	V8 series	TS2060	V7 series	TELL	US HMI	TELLUS HMI iPad	TELLUS Remote	TELLU	JS HMI	TELLUS Remote
Fuii Electric	MICREX-E series				1:1	1:n	1:1/1:n	V-Server	1:1	1:n	V-Server
oj, Licetric	MICREX-F series V4 Compatible MICREX-F Tlink		v √ -	✓ ✓ ✓	v √ -	√ -	-		√ -	√ -	√ √ *16
	MICREX-F Tlink V4 Compatible SPB(N mode)&FLEX-PC series		-	4	-	-	-	4	-	-	
	SPB(N mode)&FLEX-PC CPU FLEX-PC COM(T)	√ -	√ -	4	√ -	-	-	√ -	√ -	-	√ -
	FLEX-PC(T) FLEX-PC CPU(T)		-	4	-	-	-	-	-	-	-
	FLEX-PC(OPCN-1) MICREX-SX(Tlink)	-	-	√ √*12	-	-	-	- √*3	-	-	- √ *3.12.16
	MICREX-SX(OPCN-1) MICREX-SX(SX bus)	√ *12 √	-	√ *12 √ *12	-	-	-	√ *3.12 √ *3	-	-	✓ *3.12.16 ✓ *3.12.16
	MICREX-SX SPH/SPB/SPM/SPE/SPF series MICREX-SX SPH/SPB/SPM/SPE/SPF CPU	√ √	1	√ *12 √ *12	1	-	-	√ *3 √ *3	√ *12 √ *12	-	✓ *3.12 ✓ *3.12
Adept	MICREX-SX(Ethernet) AAC Protocol	-	-	√ *12 √	-	-	-	√ *3 -	√ *12 -	√ *12 -	√ *3.12
Allen-Bradley	PLC-5 PLC-5(Ethernet)		-		4		-		-	-	-
	SLC500(Ethernet TCP/IP) NET-FNI/SLC500 Ethernet TCP/IP)		-	4 	4	4	-	4	-	-	-
	NET-ENI(MicroLogix Ethernet TCP/IP)		-	-					-	-	-
	Micro Logix(Ethernet TCP/IP) Control Logix/Compact Logix	√ √	-	-	4	-	-	√ √*2	1	-	√ √*2
	Control Logix(Ethernet) Micro800 Controllers	√ √	-	-	4	-	-	√ *2 √ *2	4	-	√ *2 √ *2
Automationdirect	Micro800 Controllers(Ethernet TCP/IP) Direct LOGIC	-	-	-	-	-	-	√ *2 -	-	-	√ *2 -
	Direct LOGIC(K-Sequence) Direct LOGIC(Ethernet UDP/IP)		-		4	-	-	4	-	-	-
Azbil	Direct LOGIC (Modbus RTU) MX series		√ √ *0	4	4	4	-	4	-	-	-
Baldor	Mint RMx × DIC	-	-		-	-	-	-	-	-	-
Beckhoff	ADS Protocol(Ethernet) Tag ADS Protocol(Ethernet)		-	-					1	1	1
TIMON	BP Series CP Series		√ √	-		-	-		-	-	-
	XP Series S Series		√ √	-	۲ ۲	-	-	٠ ٠	-	-	-
	S Series(Ethernet) CP3E	√ √	-	-	4	-	√ *21	√ √	-	-	-
DELTA	DVP-set(MODBUS ASCII)	1	√ √	1	4	4	-	1 1	-	-	-
EATON Cutler-Hammer	ELC ECCID/ECO/ECOUL (MODBUS DT))		-	1	4	1	-	4	-	-	-
ANUC	Power Mate FACON FR series			-	4	-	-	4	-	-	-
ESTO	FACON FB series FEC			√ √	4		-		-	-	-
GE Fanuc	90 series Controller			-	4		-	4	-	-	-
	90 series(SNP) 90 series(Ethernet TCP/IP)			-			-		-	-	-
litachi	RX3i(Ethernet TCP/IP) HIDIC-S10/2alpha,S10mini		-	-	4	-	-	4	-	-	-
	HIDIC-S10/2alpha,S10mini(Ethernet) HIDIC-S10/4alpha		-	4	4	-	-	1	-	-	-
	HIDIC-S10/ABS HIDIC-S10(OPCN-1)	√ √	-	4	√ -	-	-	√ √	-	-	-
	HIDIC-S10V HIDIC-S10V(Ethernet)	√ √	-	4	4	-	-	4	-	-	-
Hitach Industrial Equipement Syster	ns HDIC-H HDIC-H (Ethernet)		*15	4	4	4	-	4	-	-	-
	HIDIC-EHV HIDIC-EHV(Ethernet)		-		4	4	-	1	1	-	1
	Universal Modbus KTO Universal Modbus TCP/IP(Ethernet)	-	-	√ √	-	-	-	-	-	-	-
DEC	Hi4 Robot(MODBUS RTU) Hi4 Robot(MODBUS RTU)			-			-		-	-	-
	MICRO Smart MICRO Smart Pentra	√ √	1	√ -	4	1	-	1	-	-	-
Jetter	MICRO Smart(Ethernet TCP/IP) JetControl Series2/3(Ethernet UDP/IP)	√ √ *17	-	-	√ -	√ -	√ -	√ -	-	-	-
JTEKT	TOYOPUC TOYOPUC(Ethernet)		√ -	√ √	4		-	√ √	1	√ √	√ √
	TOYOPUC(Ethernet PC10Mode) TOYOPUC-Plus TOYOPUC-Plus	4	-	-	4	4		4	-	-	-
	TOYOPUC-Plus(Ethernet) TOYOPUC-Nano(Ethernet)		-	-	4	4	√*21		-	-	-
RETENCE	KZ-SENES IITIK KZ-A500 CPU KZ/KV corios CPU		↓ ↓ ↓	4 	4	-	-	4 	-	-	-
	KZ24/300 CPU KV10/24 CPU					-	-		-	-	-
	KV-700 KV-700(Ethernet UDP/IP)	-	-	4	-	-	-	-	-	-	-
	KV-700(Ethernet TCP/IP) KV-1000		-	4	4	-	-	√ √	√ √	-	√ √
	KV-1000(Ethernet TCP/IP) KV-3000/5000	√ √	-	-	4	-	-	√ √	1	-	1
	KV-3000/5000(Ethernet TCP/IP) KV-7000/8000(Ethernet TCP/IP)	4	-	-	4	4		4	-	-	-
	KV Nano KV Nano(Ethernet TCP/IP)		-	-	4	-	-	4	-	-	-
COTO ELECTRONICS	SR-T SR-T	-	-	4	-	-	-	-	-	-	-
	SU/SG(K-Sequence) SU/SG(Modbus RTU)			4	4	-	-		-	-	-
S	MASTER-K10/60/200 MASTER-K500/1000		-	4	-	-	-	-	-	-	-
	MASTER-KxxxS MASTER-KxxxS CNET	√ √	1	4	4	-	-	1	1	-	√ √
	MASTER-K series(Ethernet) GLOFA CNET		-	4	4	4	√ *21 -	4	-	-	-
	GLOFA GM7 CNET GLOFA GM series CPU		1 1	-	4	-	-		-	-	-
	GLOFA GM series(Ethernet UDP/IP) GLOFA GMR series(Ethernet)	-	-	4	-	-	-	-	-	-	-
	XG1/XGK series CPU XGT/XGK series CPU		4	4	4	-		4	-	-	-
	XGT/XGI series CNET XGT/XGI series CPU			-	4 4 4	× 	-			4	
	XGT/XGI series(Ethernet) A series link		-	-			√ *21				
	A series CPU A series(OPCN-1)		- -		- -	-	-		- -	-	
	QnA series link QnA series CPU		√ √	4	4	√ -	-	4	4	√ -	√ √
	QnA series(Ethernet) QnH(Q) series link	✓ ✓	-	4	4	4	-	√ √	4	√ -	√ √
	QnH(A) series CPU QnH(Q) series CPU	√ √	√ √	4	-	-	-	√ √	-	-	-
	QnU series CPU Q00J/00/01 CPU	√ √	√ √	√ *6 √	4	-	-	√ √	√ *6 √	-	4
	QnH(Q) series(Ethernet) QnH(Q) series link (Multi CPU)	√ √	-		4	√ √	-		√ √	-	√ √
	QnH(Q) series (Multi CPU) (Ethernet) QnH(Q) series CPU (Multi CPU)	✓ ✓	-	4	4	-		4	4	-	√ √
	UnH(Q) series(Ethernet ASCII) OnH(Q) series (Multi CPU) (Ethernet ASCII)	✓ ✓ ✓	-	-		√ √	-		-	-	-
	QnU series(Built-In Ethernet) QnU series (Multi CPU) (Built-in Ethernet)	√ √ *18	-	-	4	1	√*21 √*21		-	-	-
	A NEW ATTENDED AND A SECOND STATEMENT AND A SECOND	Internet and the Allerta Allerta Allerta	DIO OTI		at a set to be for	Deres etc. and de	t d. Deburge die d		4.4		. ID

Supported -: Not supported Note 1: TELLUS HMI does not support Multi-link or Multi-link Z connection. Note 2: PLC_CTL macro command is not available for Remote mode. *1: Drivers that do not support 1:1 communication, the message "Remote mode not supported" is prompted. In such case, force to proceed. *2: In case Event Setting in V-Server is "Trigger: Memory, Type: Bit", upper bits in a double-word (bit 16 to 31) are not available. *3: Monitoring STRING type is not available. *4: Only RS-422 supported. *5: In case Event Setting in V-Server is "Trigger: Memory, Type: Bit", upper bits in a double-word (bit 16 to 31) are not available. *3: Monitoring STRING type is not available. *4: Only RS-422 supported. *5: In case Event Setting in V-Server is "Trigger: Memory, Type: Word", even double-word device is processed in word unit. *6: For Q10UDH/Q13UDH/Q20UDH/Q20UDH.connection to RS232C port on the CPU is not supported.



As of July 2021

			TELLU	S Ver.4		т	.3	
	V7 series	TELLU	IS HMI	TELLUS HMI iPad	TELLUS	TELLU	із нмі	TELLUS
		1.1	1:n	1.1/1.n	& X Common	1.1	1.n	& X Common
	-	√	~	-	v-Seivei √	√	√	v-Server √
	-	1	-	√ *21 -	1	√ *13 -	√ *13 -	√ *13 -
_	1	-	-	-	1	-	-	-
	1	-	-	-	1	-	-	-
	1	1	-	-	~	~	-	~
	1	~	-	-	~	-	-	-
-	-	1	-	-	1	1	-	1
_	1	1	1	-	1	~	~	~
_	-	~	1	√ *21	~	-	-	-
_	√ √	-	-	-	-	-	-	-
_	-	1	-	- √ *21	~	-	-	-
	-	1	1	√ *21	1	1	1	√ √
	-	1	1	√ *21	1	~	~	~
	~	~	-	-	~	-	-	-
	1	-	-	-	~	-	-	-
_	1	1	1	-	~	-	-	-
_	1	1	1	-	1	- √ *19.20	- √ *19.20	- √ *20
	1	~	1	-	√ *7	√ *19.20	√ *19.20	√ *7.20
_	-	~	~	-	√ √	-	-	-
	1	1	1	-	√ *2.5 √	1	1	√ *2.5 √
	-	1	1	-	1	1	1	√ √
	-	√ ./	√ ./	-	√ ./	1	√ ./	√ ./
	-	× √	× 	-	× √	× √	✓ ✓	× √
	-	√ √	4	- √ *21	√ √	√ √	√ √	√ √
	-	√ √ √	1	~	√ √	√ √ √	√ √	
	1	-	-	-	1	-	-	-
	1	1	1	-	1	-	-	-
	1	1	1	-	~	1	1	1
	1	1	-	-	√ 			-
	1	-	-	-	√	-	-	-
	1	1	1	-	1	~	1	-
	1	1	1	-	1	1	1	-
	1	1	~	-	~	-	-	-
	1	-	-	-	- √ *8	-	-	-
_	1	-	-	-	- √ *8	-	-	-
_	1	-	-	-	√ *8 ∕ *9	-	-	√ *8
_	-	-	-	-	√ *8	-	-	√ *8
	~	-	-	-	-	-	-	-
_	1	-	-	-	-	-	-	-
	1	1	1	√ √	√ *8 √ *8	1	1	√ *8 √ *8
	1	-	-	-	/ *9	-	-	- / *9
	-	~	~	~	√ *8	-	-	-
	-	-	-	-	√ *8	-	-	-
-	1	-	-	-	√ *8 √ *8	-	-	√ *8.16 -
_	1	-	-	-	√ *8 -	-	-	-
_	-	1	1	-	1	√ -	√ -	√ -
	~	-	-	-	-	-	-	-
	-	~	~	-	~	-	-	-
	-	1	1	-	1	-	-	-
	1	-	-	-	1	-	-	-
	1	-	-	-	1	-	-	-
	√ √	√ √	-	-	√ √	-	-	-
	-	· ·		√		-	-	-
	~	1	1	-	~	~	~	-
	-	~		-	~	-	-	-
	-	-	-	-	~	-	-	-
-	1	1	1	-	√ √	1	√ √	√ *10 √ *10
	1	1	1	√ -	1	4	1	1
	-	~	~	-	· ·	~		
	-	~	~	-	√ √	-	-	-
	-	1	1	- √ *21	1	-	-	-
	√ √	-	-	-	- √ *11	-	-	- √ *11
			4	-	√ *11 √ *11			√ *11 √ *11
	-	· ·	~	-	√ *11 / *11	-	-	- / #11
	-	1	1	~	√ *11	-	-	-
	-	√ √	1	√ *21	√ *11 √ *11	-	-	-
	-	-	-	√*21	√*11	-	-	-
	-	1	1	- √ *21	1	-	-	-
	-	-	-	-	-	-	-	-
	1	-	-	-	1	-	-	-
	1	-	-	-	1	-	-	-
	-	-	-	-	1	-	-	-
	√ -	√ √	√ √	-	√ √	√ -	√ -	√ -
	1	· ·	~	1	- 	1	1	1
	-	~	~	√ *22	~	-	-	-
	-	1	-	-	1	-	-	-
-	-	1	-	-	1	-	-	-
-	1	1	-	-	1	-	-	-

*7: Only "Transmission Mode 1" supported. ("Transmission Mode 2", which is signed BCD, is not supported.) *8: PLC memory is not available when Event Setting in V-Server is "Trigger: Memory, Type: Bit". *9: Integrated to DMC50(COM). * 10: Only "Transmission Mode 2" supported. *11: PLC_ULR macro command is not supported. *12: SPH3000MM/SPH5000M is not supported. *13: SPU device is not supported. *14: Integrated to T series/Y series/T compatible). *15: RS-232C connection not supported. *16: Only is eries supported. *17: V9 series not supported. *10: Only V9 series to UNDY 50: Only "Compatible.). *15: RS-232C connection not [Target Port No.] in the [Connection Device Selection] settings. *22: Sub Station is not supported. *19: When using EMn (extended data memory), specify the bank number 0 to C (HEX). *20: CP series is not supported. *21: Select "LAN(TCP)" for [Target Port No.] in the [Connection Device Selection] settings. *22: Sub Station is not supported.

Temperature controllers, Servos and Inverters compatible with TELLUS

		V9 series				TELLUS Ver.4	1	TELLU	US Ver.3	
Manufacturer	Models	V8 series TS2060i	TS2060	V7 series	TELLUS HMI	TELLUS HMI iPad	TELLUS Remote & V-Server	TELLUS HMI	TELLUS Remo & V-Server	
Fuji Electric	PYX(MODBUS RTU) PYH	-	√ -	√ √	√ -	-	√ -	-	-	
	PXR(MODBUS RTU) PXF(MODBUS RTU)	√ √	1	√ -	√ √	-	4	-	-	
	PXG(MODBUS RTU) PXH(MODBUS RTU)	√ √	1	√ √	√ √	-	4	-	-	
	PUM(MODBUS RTU)			· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	-		-	-	
	F-MPCU4P(Loader) F-MPC Series /FePSU				√ √	-		-	-	
	FVR-ETTS FVR-ETTS(MODBUS RTU)			√ √	√ √	-	4	-	-	
	FVR-C11S FVR-C11S(MODBUS RTU)	-	-	√ √	-	-	-	-	-	
	FRENIC5000G115/P115 FRENIC5000G115/P115(MODBUS RTU)			√ √	√ √	-	4	-	-	
		-	-		-	-	-	-	-	
	FRENIC-Ace(MODBUS RTU)			-	4 	-	√ √	-	-	
	FRENIC-Eco(MODBUS RTU) FRENIC-HVAC/AQUA(MODBUS RTU)			-	4	-	√ √	-	-	
	FRENIC MEGA(MODBUS RTU) FRENIC MEGA SERVO(MODBUS RTU)		4	-	√ √	-	4	-	-	
	FRENIC-Mini(MODBUS RTU)		4	4	√ /	-	1	-	-	
	FRENIC-VGI (MODBUS RTU)			-	~	-		-	-	
	HFR-C9K			-	√ √	-		-	-	
	HFR-C11K HFR-K1K			-	√ √	-	√ √	-	-	
	PPMC(MODBUS RTU) FAI DIC-alpha series	√ √	4	4	4	-	1	-	-	
	FALDIC-W series	~		~		-	√ 	-	-	
	PH series PHR(MODBUS RTU)			4	4	-	√ √		-	
	APR-N(MODBUS RTU)	√ √	1	-	√ √	-	1	-	-	
	ALPHAS (MODBUS RTU)	1	1	-	1	-	1	-	-	
	ALPHA7 (MODBUS RTU)	× 	1	-	1	-	1	-	-	
	WE IMA(Ver.A)(MODBUS RTU) WE1MA(Ver.B)(MODBUS RTU)	√ √	4	-	√ √	-	1	-	-	
	WSZ series WSZ series(Ethernet)	√ √	-	-	√ √	- √*3	1	-	√ -	
gilent	4263 Series	· · · · · · · · · · · · · · · · · · ·	1	- /		-	· · · · · · · · · · · · · · · · · · ·	-	-	
2011	SDC15		4	-		-		-	-	
	SDC20 SDC21			√ √	√ √	-	√ √	-	-	
	SDC25/26 SDC30/31			-	۲ ۲	-	↓ ↓	-	-	
	SDC35/36			- -		-		-	-	
	SDC45/46 SDC40A			-	√ √	-	√ √	-	-	
	SDC40G DMC10		4	√ √	√ √	-	1	-	-	
	DMC50(CTRL)	*1	*1	1	*1	-	*1	-	-	
	AHC2001 AHC2001		~	~	~	-		-	-	
	DCP31/32				4			-	-	
	NX(CPL) NX(Modbus RTU)			-	√ √	-	√ √	-	-	
&D	NX(Modbus TCP/IP)	4	-	-	√ √	√ -	1	-	-	
	AD4404(MODBUS RTU)		- -	· · · · · · · · · · · · · · · · · · ·		-	-	-	-	
osch Rexroth	IndraDrive		-	-	√ √	-		-	-	
HINO	DZ1000(MODBUS RTU) DZ2000(MODBUS RTU)	-	-	√ √	-	-	-	-	-	
	KP1000	-	-	4	-	-	-	-	-	
	DP1000	~	~	1	1	-	~	-	-	
	DB1000 DB1000B(MODBUS RTU)	~	-	-	-	-	-	-	-	
	KR2000(MODBUS RTU) LT230(MODBUS RTU)		4	-	√ √	-		-	-	
	LT300(MODBUS RTU)	4	4	-	4	-	√ √	-	-	
anfoss	VLT series	-	-	1	-	-	-	-	-	
LEIN INU UNIN STSTEMS	PMAC(Ethernet TCP/IP)	√ √	-	-	4	-		-	-	
JROTHERM ATEK AUTOMATION	2400 series (MODBUS RTU) FACON FBs series(Ethernet)	-	-	-	-	- √ *3	-	-	-	
ammaflux	TTC2100 G24(Ethernet TCP/IP)	√ √	√ -	√ -	√ √	-	√ √	-	-	
BM	FIT/5 /AD103	-	-	4	-	-	-	-	-	
uachi industrial Equipment Systen	SJ700 series			-	√ √	-	4	-	-	
	SJ Series P1(MODBUS RTU)	-	-	√ 	-	-	-	-	-	
oneywell	Universal Modbus RTU DC1000	-	-	1	-	-	-	-	-	
I	Super SEL Controller	-	-	· · · · · · · · · · · · · · · · · · ·	-	-	-	-	-	
	ROBO CYLINDER(RCP2/ERC)			√ √	↓ ↓	-	√ √	-	-	
	ROBO CYLINDER(RCS) ROBO CYLINDER(RCS/E-CON)	-	-	-	-	-	-	-	-	
	TX-C1 PCON/ACON/SCON/MODBLIS RTU)	-	-	√ √	-	-	-	-	-	
EYENCE	DL-RS1A(SK-1000)	· · ·		-	· · · · · · · · · · · · · · · · · · ·	-	· · · · · · · · · · · · · · · · · · ·	-	-	
oganei	IBFL-TC		1	-	√ √	-	√ √	-	-	
	ABSRCD/ABSRCX ABPRC	-	-	√ √	-	-	-	-	-	
enze	Servo Drive 9400(Ethernet TCP/IP)	~	-	-	√ -	√ -	√	-	-	
	iG5	-	-	~	-	-	-	-	-	
ITSUBISHI ELECTRIC	FR-*500	-	-	-	-	-	-	-	-	
	FR-V500 MR-J2S-*A	√ √	1	√ √	√ √	-	1	-	-	
	MR-J2S-*CL	~	· ·	√		-		-	-	
	MR-J3-*A	~	-	√ √	-	-	- -	-	-	
	MR-J3-*T MR-J4-*A	√ √	1	-	1	-	1	-	-	
	FR-*700(MODBUS RTU)	-	-	1	-	-	-	-	-	
00G	J124-04x series	√ √	~	-		-	4	-	-	
-SYSTEM	R1M series (MODBUS RTU) R5 series (MODBUS RTU)	-	-	√ √	-	-	-	-	-	
IKKI DENSO	SQB-6432B	- /	- /	√	- /	-	-	-	-	
HKURA	EC5500S	-	-	1	-	-	-	-	-	
	EC5600S	-	-	√ √	-	-	-	-	-	
	EC5900A		-		-		-			

	10 sector			TELLUS Ver.4			TELLUS Ver.3		
Manufacturer	Models	V9 series V8 series TS2060i	TS2060	V7 series	TELLUS HMI	TELLUS HMI iPad	TELLUS Remote & V-Server	TELLUS HMI	TELLUS Remote & V-Server
OMRON	ESAK ESAK-T	1	1	1	√ √	-	1	-	-
	ESAN/ESEN/ESCN/ESGN	1	1	1	1	-	1	-	-
	ESCC/ESEC/ESAC/ESDC/ESGC	~	√ √	-	√ √	-	~	-	-
	ESCK ESCK-T	1	1	1	1	-	1	-	-
	ESCN-HT	1	~	-	~	-	1	-	-
	ESEK ESEK-T	-	-	1	-	-	-	-	-
	ESZD	1	~	1	1	-	1	-	-
	E5ZE F5ZN	1	1	1	1	-	1	-	-
	V600/620/680	1	1	1	1	-	1	-	-
	3G3MV(MODBUS RTU) KM20	-	-	-	-	-	-	-	-
	KM100	1	1	-	1	-	1	-	-
	EJ1	1	-	-		-	1	-	-
Orientalmotor	High-efficiency AR Series(MODBUS RTU)	1	1	-	1	-	1	-	-
Panasonic	MINAS A4 Series	4	1	-	√ √	-	1	-	-
	LP-200/LP-F10	-	-	1	-	-	-	-	-
	LP-300	-	-	√ √	-	-	-	-	-
	LP-V10	-	-	1	-	-	-	-	-
	KW Series	-	~	-	-	-	-	-	-
	LP-RF series	√ *2 (*2	~	-	1	-	1	-	-
Parker	LVD/HPD	-	-	~	-	-	-	-	-
RKC	SR-Mini(MODBUS RTU)	4	1	1	1	-	4	1	1
	SR-Mini(Standard Protocol)	1		1	1	-	1	-	-
	REX-F400/F700/F900(Standard Protocol) REX-F9000(Standard Protocol)	1	4	1	4	-	1	-	-
	SRV(MODBUS RTU)	1	1	1	1	-	1	-	-
	REX-B800(Standard Protocol) MA900/MA901(MODBLIS BTLI)	-	-	1	-	-	-	-	-
	SRZ(MODBUS RTU)		~	-	~	-	1	-	-
RS Automation	FB100/FB400/FB900(MODBUS RTU)	1	1	-	1	-	1	-	-
N3 Automation	Moscon-F50(MODBUS RTU)	~	~	-	↓ ↓	-	√ √	-	-
SAMSUNG SANKEN ELECTRIC	MOSCON-E7 SAMCO-e	-	-	1	-	-	-	-	-
Si un en eccentre	SAMCO-vm05	-	-	1	-	-	-	-	-
SANMEI	Cuty Axis Cuty Axis3	-	-	1	-	-	-	-	-
SanRex	DC AUTO (HKD type)	1	~	-	1	-	1	-	-
SANYO	PB1 series	-	-	1	-	-	-	-	-
DI IANT	DS-32D	1	~	1	~	-	1	-	-
SHIMADEN	Shimaden Standard Protocol	1	1	1	1	-	1	-	-
STIINING TECTINGS	FC Series	1	~	~	~	-	~	-	-
	GC Series	1	1	1	1	-	1	-	-
	JCx-300 Series	~	1	1	1	-	~	-	-
	PC-900 PCD-33A	1	1	-	1	-	1	-	-
	ACS-13A	~	1	-	1	-	~	-	-
	ACD/ACR Series WCL-13A	1	1	-		-	1	-	-
<i></i>	PCA1 Series	1	1	-	1	-	1	-	-
SICK Siemens	DME3000 S120(Ethernet ISOTCP)	-	-	-	-	-	-	-	-
	MicroMaster 400	-	-	1	-	-	-	-	-
SUS	XA-A*	-	-	-	-	-	-	-	-
тоно	TTM-000	1	1	1	1	-	1	-	-
	TTM-200(MODBUS RTU)	1	~	1	1	-	1	-	-
TOKYO CHOKOKU PRODUCTS	MB3315/1010	1	1	-	1	-	1	-	-
TOSTIBA	VF-S9	~	√ √	√ √	√ √	-	~	-	-
	VF-S11 VF-S15	1	1	1	1	-	4	-	-
	VF-A7		1	1	1	-	~	-	-
	VF-AS1 VE-P7	1	1	1	1	-	1	-	-
	VF-PS1	1	1	1	1	-	1	-	-
	VF-FS1 VF-MB1	1	1	-	1	-	1	-	-
	VF-nC1	1	1	1	~	-	1	-	-
TOSHIBA MACHINE	VE-nC3 VELCONIC Series	4	1	-	1	-	1	-	-
ULVAC	G-TRAN Series	1	1	-	1	-	1	-	-
UNIPULSE	F340A F371	√ √				-		-	-
	F600	-	-	1	-	-	-	-	-
	F720A	4	1	-	1	-	1	-	-
	F805A	1		-	· · · · · · · · · · · · · · · · · · ·	-	1	-	-
TAMAHA	SRCD/SRCX	-	-		-	-	-	-	-
	PRC	-	-	1	-	-	-	-	-
Yaskawa Electric	VS mini V7 series E-POSI series	-	-	1	-	-	-	-	-
()	DX200(High-Speed Ethernet)	1	-	-	1	-	1	-	-
roкogawa Electric	UT750	4	1	1	1	-	1	-	-
	UT550	1	1	1	1	-	1	-	-
	U1520 UT350	4	1	1	1	-	4	-	-
	UT320	1	1	1	1	-	1	-	-
	U12400/2800 UT450		1	-	1	-		-	-
	UP350	-	-	1	-	-	-	-	-
	UP550 UP750	-	-	1	-	-	-	-	-
	UM330	-	-	1	-	-	-	-	-
	UM350 UT32A/35A(MODBUS RTII)	-	-	-	-	-	-	-	-
	UT52A/55A(MODBUS RTU)	1	1	-	1	-	1	-	-
	UT/SA(MODBUS RTU) µR10000/20000(Ethernet TCP/IP)	1	-	-	1	-		-	-
Others	MODBUS RTU	1	1	-	1	-	1	~	~
	MODBUS TCP/IP (Ethernet) General AF-LINK		-	-	-	-	-	-	-
	Modbus Free	-	-	1	-	-	-	-	-

*:Supported -: Not supported Note: TEMP_CTL macro command is not available for Remote mode. *1: Integrated to DMC50(COM). *2: V8 series not supported. *3: Select "LAN(TCP)" for [Target Port No.] in the [Connection Device Selection] settings.

As o	f July	2021
------	--------	------